

# ASSEMBLY INSTRUCTIONS

## THE SET CONSISTS OF THE FOLLOWING PARTS

- 4 PIECES OF AK60060 MOUNTING BRACKET
- 4 WASHERS
- 4 CONCRETE SCREWS 8X70MM

## INSTRUCTIONS

1. PLACE THE MOUNTING BRACKETS AT THE FOUR DESIGNATED PLACES AND MARK THE HOLES WITH A MARKER
2. USE AN 8 MM. DRILL TO PRE-DRILL THE HOLES
3. INSERT THE CONCRETE SCREWS

